



Cinderella Toilet User & Maintenance Instructions

How to Use

1. Lift the lid and insert a liner.
2. Use the toilet as normal.
3. Close the lid and press the Start button to begin the incineration cycle.
4. The display will indicate that incineration is in progress.
5. The display will indicate when it is ready for the next use.

Weekly Maintenance

- Empty the ash pan and wash it with hot water using the brush provided.
- Run the Steam Clean cycle as described in the manual:
Dissolve 4 tablespoons of bicarbonate of soda in 1 litre of hot water.
Pour the solution into the ash pan.
Reinsert the ash pan and press the Start button.

Periodic Maintenance

Every 500 uses (1 box of 500 liners):

1. Clean the catalytic converter using the funnel provided.
2. Clean the fan and exhaust outlet with the supplied bottle brush.

Every 12–24 months:

- Clean the flue using the brush assembly provided.

Important Notes

- ⚠ A liner must be used for every use (both liquid and solid waste).
- ⚠ Do not overfill the ash pan – this will cause damage.
- ⚠ Failure to follow these instructions will void the warranty.

